

# Above-The-Floor Spotting Instructions

(Upholstered Furniture ☞ Draperies ☞ Wall Coverings)

## READ ALL INSTRUCTIONS BEFORE PROCEEDING

- A. If possible, remove liquid spots and spills before they dry.
- B. Lift any solids or semi-solids by pinch blotting, vacuuming or scooping.
- C. Blot or wick-up liquids with a white terry towel or white paper towels, **NEVER RUB!**
- D. Before applying **ANY** cleaning agent to a spot or spill **ALWAYS PRETEST** fabric for colorfastness. (See colorfastness test below.)
- E. Do not attempt to remove any spot (other than using steps A, B and C) on delicate fabric such as velvet, chenille, linen, silk and fabrics with polished finishes until you call your local Fiber-Seal Service Center.
- F. Using the guide to the right, apply the recommended Fiber-Seal spotting agent(s) to a white terry towel and press to the spot. **NEVER RUB!**
- G. Continue to apply the cleaning agent(s) and blot. Repeat as long as the spot continues to transfer to your towel. **STOP** when no more of the spot transfers.
- H. If a spot does not respond to this procedure, call your Fiber-Seal Service Center for assistance.

## COLORFASTNESS TEST:

Apply a small amount of the cleaning agent to an inconspicuous area. Let stand for 5 minutes and gently wipe with a white terry towel. **IF ANY COLOR MOVEMENT OR UNUSUAL CHANGE IS DETECTED, STOP** and call your local Fiber-Seal Service Center.

## YOUR FIBER-SEAL RESOURCES:

Fabric Sponge ☞ Kleen-Tec ☞ pHnominal ☞ ColorReneu (see packaging for complete application instructions.)

Find your spot/spill on the list below and follow the steps, using the six Fiber-Seal solutions. Read all instructions before proceeding.

## THE FIBER-SEAL SOLUTIONS

1. Vacuum    2. Blot/Lift    3. Fabric Sponge    4. Kleen-Tec    5. pHnominal    6. ColorReneu

Acne cream – 2 – 4

Ashes – 1 – 3

Beer – 2 – 5

Bleach – 2 – 5

Blood – 2 – 5 – 6

Butter – 2 – 4

Catsup – 2 – 4 – 5

Chocolate – 2 – 3 – 4 – 5

Coffee – 2 – 5 – 6

Cola – 2 – 5 – 6

Cosmetics – 1 – 2 – 3

Crayon – 2 – 3 – 4

Excrement – 2 – 5 – 6

Glue – 2 – 4 – 5

Graphite – 1 – 2 – 3

Gravy – 2 – 4 – 5

Grease – 2 – 3 – 4

Gum – Freeze – Lift

Ice Cream – 2 – 4 – 5

Ink – 2 – 3

Iodine – 2 – 5

Jelly – 2 – 5

Kool-aid (Juice) – 2 – 4 – 5 – 6

Lipstick – 2 – 3 – 4

Liquor – 2 – 5 – 6

Make-up (liquid) – 2 – 4 – 5

Mascara – 1 – 2 – 3

Medicine – 2 – 5 – 6

Mildew (dry) – 1 – 3 – 4

Milk – 2 – 4 – 5

Mud (dry) – 1 – 2 – 3 – 4 – 5

Mustard – 2 – 4 – 5 – 6

Nail Polish – 2 – 3 – 4

Newsprint – 3 – 4

Paint (Latex) – 2 – 5

Paint (Oil) or (Dry Latex) – 2 – 4 – 5

Plant Food – 2 – 5

Plaster (Dry) – 1 – 2 – 3

Play-doh – 1 – 2 – 3 – 4 – 5 – 6

Pollen – 1 – 3

Salad Dressing – 2 – 4

Sauces – 2 – 4 – 5 – 6

Shoe Polish – 2 – 3 – 4

Soft Drink – 2 – 5 – 6

Soot – 1 – 3

Syrup – 2 – 5

Tar – 2 – 3 – 4

Tile Cleaner – 2 – 5

Toner (Powder) – 1 – 3

Toothpaste – 2 – 5

Unknown Stains – 1 – 2 – 3 – 4 – 5 – 6

Urine – 2 – 5 – 6

Varnish – 2 – 4

Vomit – 2 – 5 – 6

Wax – Freeze – Lift

Wine – 2 – 5 – 6

**If the procedure is not working, call your local Fiber-Seal Service Center immediately.**